



Spacing requirements for BoraBora Models

Horizontal spacing for leaves is as follows:

Spacing (or gap) for BoraBora Model:

29% to 31% = 4 inches or 10 cm gap,
32% to 33% = 4,5 inches or 11,5 cm gap,
34% to 36% = 5 inches or 12,5 cm gap.

- Leaves shall always be installed in staggered rows all over the roof.
- On positive angles, there shall be a minimum of 3 hips for every 2 running feet (1 hip every other row).
- It is compulsory to overlap leaves on positive angles before the installation of the hips.
- On negative angles, there shall be roof gutters or equivalent protections.
- The roofing and its components shall comply with local or national building regulations in force.

Installation on slopes less than 30% is strongly disadvised.
